

BOXX Slides are required for adding boxes to the upgradable shelf. This includes the S, T, L, LS and M-BOXXes.

NOTE: BOXX Slides are not compatible with the shelf tray or when using the upgradeable shelf lip. The shelf lip, when present, should be removed prior to the addition of the BOXX slides.


1. Insert BOXX Slide into the slots in the upgradeable shelf.



NOTE: Check BOXX spacing requirements prior to installing BOXX Slides.

2. Pull the BOXX slide forward (towards the front of the shelf) as far as it will go.

3. Press the BOXX slide down starting in the middle and moving to the back. The BOXX slide will snap into place when fully seated on the shelf.





4. To remove the slide from the shelf, pinch the tabs at the rear of the BOXX slide from the underside of the shelf. Removal is the opposite of installation.

NOTE: A small pair of pliers will help with BOXX slides installed in the corners of the shelves.

NOTE: Refer to the next page for BOXX spacing tips.

DON'T FORGET BOXX SLIDES

of BOXX slides needed =
of BOXXes per shelf + 1



BOXX Spacing for Wide 4 and Wide 6 Upgradeable Shelves

4450-1
4460-1
4460-2
4480-1
4480-2
44100-1
44100-2

4660-1
4660-2
4680-1
4680-2
46100-1
46100-2

