
SoftimeSHELF STAXX ACCESSORY
INSTALLATION INSTRUCTIONSLIFT FLAP KITS: LF40-18& LF60-18



The LF40-18 and LF60-18 Lift Flap Kits can be mounted on all 60, 80 and 100-grid Shelf Staxx. Each Lift Flap Kit includes a door with an attached hinge and gas shock, and mounting screws and nuts.

1000002820 HARDWARE KIT		
QTY	PART #	DESCRIPTION
4	71004896	SCREW (M6 X 16)
4	71003884	PAWL NUT (M6)




1. Determine the desired location to mount the Lift Flap Kit. Open the lift flap and fasten the hinge plates to the inside of the end panels with the hardware provided.

NOTE: For tips on installing a lift flap above a shelf tray or upgradeable shelf please see page 2.



2. Close the door and check for interference. Make adjustments as needed.






SoftimeSHELF STAXX ACCESSORYLIFT FLAP KITS: LF40-18INSTALLATION INSTRUCTIONS& LF60-18



Optional Installation Locations:

Shelf trays and Upgradeable shelves.


1. Shelf tray: The Lift Flap kits may be installed over a shelf tray.





1a. The lift flap hinge plate should be mounted just above the shelf tray.

DO NOT mount the hinge plate inside the shelf.



NOTE: Shelf lip is required to eliminate gaps.



2a. The lift flap hinge plate should be mounted just above the shelf and removeable lip.

DO NOT mount the hinge plate inside the shelf.

