




The Multislide MS24 includes the Multislide tray, 2 telescopic slides, 2 box clips and mounting screws and nuts.

Prior to mounting the MS24, make sure there is enough space available for installing Axxessory Boxxes. Refer to the back of the Exxpand Installation instructions manual for BOXX space requirements.

1000002820 HARDWARE KIT		
QTY	PART #	DESCRIPTION
4	71004896	SCREW (M6 X 16)
4	71003884	PAWL NUT (M6)



1. Determine the desired height of the MS24 and install each telescopic slide with the provided hardware. Install the slides so that the retaining clip is positioned toward the front of the unit and is pointed up (circled in top photo).

**NOTE:** Screws must face outwards.

**NOTE:** Be sure to mount the telescopic slides at the same grid height on the left and right Staxx end panels.




2. Extend the rails of the Multislide outward.

3. Insert the front of each rail into the molded pockets on the underside of the tray. Make sure to align the notches along the underside edges of the tray with the tabs on the telescopic slides. Apply slight pressure along the outside edges and rear of the tray to snap it into place.

\*Additional details for tab/slot alignment on page 2.

4. Close the MS24 and check for interference and proper operation.

**NOTE:** Be sure to check that the tray is fully snapped down onto slide tabs.



5. Box clips can be inserted at 4 positions.

**NOTE:** If any standard size SBK Axxessory Boxxes are to be used then the tabs need to be inserted in the rear slots.

\*Additional box clip details are on page 3.







There are 4 tabs on the forward extension arm of the MS24 telescopic slide. All 4 tabs will clip into the MS24 tray.




There are 4 corresponding notches on the underside of the tray, running along the left and right edges.

Insert the front of the telescopic rail into the molded pocket, align the tabs and notches, and apply pressure to snap the tray into place.





The box clip will fit 4 predetermined positions on the MS24 tray; 2 in the rear and 1 each on the right and left sides.



To insert, squeeze the clip legs together.



While still squeezing the clip slide it into the desired position and release.

